
DENTON PULLER BP-100

The DENTON PULLER will provide you with years of efficient and reliable service in removing automotive starter needle bearings, bushings and alternator bearings.



It's simple, fast and efficient!

1. Choose the appropriate gripper, insert it into the puller and turn it 90^0.
2. Hold the housing firmly.
3. Grasp the handle and pull down.

7 GRIPPERS ARE INCLUDED WITH YOUR PURCHASE 0F THE DENTON PULLER BP-100